



# LS-2 Cleaning

VACUUM FILTER MACHINE FOR FRYING OIL  
**Service Bulletin**

For daily cleaning, only use hot water to rinse oil residue and crumb debris. Soap is not to be used except for oil build up around the machine frame and/or caster wheels.



## Filter Pan

*For best results, use a pre-rinse hot water sprayer to wash debris from the removeable filter pan.*

Spray away from the sump suction hole and drain crumb/water debris into compartment or mop sink.

Flush water down quick disconnect/hose opening to remove any crumbs from suction elbow fitting.

Stand it upright with the hose on the top, so that any water that may be in the pick opening will run out.

Always wipe dry using a towel to remove any water left in the pan. Frame in one hand and removing the glass pipette by the rubber stopper.

