



LS-2 Cord

VACUUM FILTER MACHINE FOR FRYING OIL
Service Bulletin

NOTE: BE SURE TO REMOVE THE POWER TO THE UNIT PRIOR TO MAKING THESE REPAIRS. IF THE CORD IS REPAIRED, IT IS RECOMMENDED THAT IT BE REPLACED



POWER CORD REPAIR

Remove the 6 Phillips screws from the top cover and you can remove the cover



Once the cover is removed you should be able to locate the black plastic nut on the three wires. (Black, Green, White)

Push the cord back into the hole



Secure the new back on the fitting and tighten down. You will need a pair of pliers to do this

Place the top back and the unit and reinstall the 6 Phillips screws that hold the cover in place



NOTE: Wipe down the power cord

You may now reassemble the unit and use it.